




PARTS BREAKDOWN

Parts List For Air Hydraulic Bottle Jack 14460





PARTS BREAKDOWN

Parts List For Air Hydraulic Bottle Jack 14460

ITEM #	DESCRIPTION	Q'TY	ITEM #	DESCRIPTION	Q'TY	ITEM #	DESCRIPTION	Q'TY
14460-001	Pump Cylinder	1	14460-031	Oil Filler Plug *	1	14460-061	Font Handle	1
14460-002	Y-seal *	1	14460-032	Snap Ring	1	14460-062	Rear Handle	1
14460-003	Nylon Gasket *	1	14460-033	O-ring Retainer	1	14460-063	Hex Nut	1
14460-004	Copper Washer	1	14460-034	O-ring *	1	14460-064	Lock Washer	1
14460-005	Nut	1	14460-035	Seal Washer	1	14460-065	Flat Washer	1
14460-006	Butterfly Spring	1	14460-036	Piston Ring	1	14460-066	Cross head socket cap screw	1
14460-007	Socket head cap screw	8	14460-037	Ram Assy	1	14460-067	Hex Nut (thin)	2
14460-008	Base Cover	1	14460-038	Bushing	2	14460-068	Return Spring	2
14460-009	Steel Ball	4	14460-039	O-ring *	1	14460-069	Screw	2
14460-010	Air Motor Housing	1	14460-040	Snap Ring	1	14460-070	Spring Lid	1
14460-011	Nut	1	14460-041	Steel Ball	1	14460-071	Snap Ring	1
14460-012	Spring	1	14460-042	Safety Valve Ball Seat	1	14460-072	Washer	1
14460-013	Washer	1	14460-043	Safety Valve Spring	1	14460-073	Steel Ball	1
14460-014	Air Pump Plunger	1	14460-044	Safety Valve Adj screw	1	14460-074	O-ring *	3
14460-015	Air Piston Base	1	14460-045	O-ring *	1	14460-075	Nylon Gasket *	2
14460-016	O-ring *	2	14460-046	Screw	1	14460-076	Nylon Gasket *	2
14460-017	Air Shuttle Valve	1	14460-047	Copper Washer *	4			
14460-018	O-ring *	2	14460-048	Valve Block Assy	2			
14460-019	Air Piston	1	14460-049	Release Assy	1			
14460-020	Socket head cap screw	3	14460-050	Steel Ball	1			
14460-021	Shuttle Valve Seal	1	14460-051	Link Pin	2			
14460-022	O-ring *	2	14460-052	Pin	3			
14460-023	O-ring *	1	14460-053	Pump Cylinder	1			
14460-024	Top Cover	1	14460-054	O-ring *	2			
14460-025	Snap Ring	1	14460-055	Nylon Gasket *	1			
14460-026	O-ring *	2	14460-056	Dustproof Ring *	1			
14460-027	Coupler	1	14460-057	Pump Plunger	1			
14460-028	Air Hose Assy	1	14460-058	Pump Plunger Pin	1			
14460-029	Air Valve Assy	1	14460-059	Link	1			
14460-030	Oil Tank Assy	1	14460-060	Socket	1			

2347 Circuit Way, Brooksville, Florida, USA 34604
 Phone: (+1) 352-799-1111 Toll Phone: (+1) 877-775-4AME (4263)
 Fax: (+1) 352-799-1112 E-mail: sales@ameintl.net www.ameintl.net